

Stretch Form Fit Recliner Slipcover

Step by Step Instructions for Medium and Large Recliners

It's as Easy as 6 Steps to a SURE FIT with our 10-Minute Makeover!

1 LOCATE
sewn-in labels for "Center Front", "Top to Back", "Front Seat", "Left and Right Arms".



2 ARM COVERS
Recline backrest slightly and raise footrest for all steps. Locate labels marked Right and Left Arm. Line up top area and evenly pull down towards the bottom tucking the fabric in seat crevices first. Tug and stretch to pull under bottom to hold securely.

3 TOP COVER

Top to Back



From the back, pull center cover over chair fitting it evenly as you work your way down. Front area should tuck and secure where top meets back of seat.

4 TOP BACK COVER
should be pulled down evenly. Secure by tucking as you make your way downward. Really pull "down and under" keeping it taut and stretching it under bottom to hold. Use elastic loops to secure the cover under the recliner.



5 SEAT COVER
locate "Front" label and place around footrest. Pull evenly towards the back adjusting and tucking excess material tightly into crevices between arms and back. After each section is complete smooth out any excess by stretching and tucking.



6 FINISHED
recliner cover should fit snug and contoured to each section. It's "sure" to make a positive impression!



NOTE: side pocket should be on left and handle on the right.