

Tailored Fit Furniture Slipcover

Step by Step Instructions for SOFA, LOVESEAT or CHAIR

It's as Easy as 6 Steps to a SURE FIT with our 10-Minute Makeover!

1 LOCATE
the sewn-in "Center Front" and "Center Back" labels. Also look for the positioning stickers for the left and right arms.




2 DRAPE
slipcover over furniture with seat cushions in place starting from the center top working your way around all sides. Align pleated corners with top corners of furniture.

3 PULL DOWN
fabric so it touches the floor evenly on all four sides. Adjust arm height and shape by pulling down and tucking under skirt and into seat crevices.



4 BACK COVER
Pull side and back sections together to meet at the back bottom corner. Adjust and smooth fabric over the hidden, fabric covered, elastic band.



5 TUCK & SMOOTH
to fit and contour shape, working from the arms to the back. When you get to the cushions LIFT and WRAP the elastic under the back and sides, pushing down and under the cushions. Smooth excess fabric by tucking it into the creases as you make your way around the furniture.

6 WHEN FINISHED
your slipcover will be neat and tailored! Now you're ready to accent with decorative pillows. It's "sure" to make a positive impression!



NOTE: arms should line up to flatter the width and shape of the original furniture style.